Firestick Remote Layout Chart

SPEAKER FOR ALEXA
Speak into this when talking to Alexa.

POWER BUTTON
Will turn On/Off your TV.
(not available with all models)

PAIRING LIGHT
Will ONLY flash when in pairing mode with your Firestick.

ALEXA
Hold down and speak into speaker at top of remote.

DIRECTIONAL BUTTONS
The outer circle/ring is for UP, DOWN, LEFT, RIGHT

HOME BUTTON
To go to the Homepage of the Firestick, press this once

ENTER/SELECT BUTTON
Press on the inner circle to make a selection

BACK BUTTON
To go to the previous screen, press this once.

MENU BUTTON
You will not use this often.

REWIND BUTTON
Press this to rewind through a TV show or Movie

FORWARD BUTTON
Press this to forward through a TV show or Movie

VOLUME CONTROL
Use this to control your volume UP and DOWN
(not available with all models)

PLAY/PAUSE BUTTON
Use this to play and pause a TV show or Movie

MUTE BUTTON
To mute the volume on your television.
(not available with all models)